

正面

尺寸142. 5*210MM

反面

- Never disassemble the chop cup or remove the motor while the blade is running.
- Recommended to be secured by one hand during operation.
- The chopper will stop automatically after 30 seconds of operation to protect the battery, press the power button again to re-start.



WARNING!

- DO NOT put hot ingredients or liquid above 131°F in the cup to avoid bursting, splashing and to prevent scalding.
- Do not chop ice cubes, frozen fruit, or meat.
- DO NOT squeeze, puncture, or short circuit the product or put it into water, fire or use in an environment where the temperature is higher than 140°F.
- Do NOT operate the product without anything in the cup.
- Do NOT expose the product to high temperatures, strong magnetic fields, near flammable and explosive gases (such as natural gas, methane, etc.) in order to avoid accidents such as abnormal operation and/or fire.
- The appliance must rest for 5 minutes for every 4 cycles to protect the motor from overheating.
- To avoid deforming or damaging parts, do not put any piece in the microwave oven or hot water above 140°F.
- The product has built-in lithium batteries. Pay attention to the following:
 - Only use and store the product in an environment where the temperature is between 32 to 140 °F.
 - Re-charge every three months to prevent battery damage.
 - Charging time may be longer when the room temperature is below 50°F.
 - Do not attempt to dismantle the product. Fire risk exist if the batteries are damaged.
 - Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium or Nickel Metal Hydride) batteries.
 - Do not incinerate or compost the batteries.
 - Do not dismantle the chopper to replace these batteries on your own.
 - Do not dispose of batteries in fire.
 - Batteries should be recycled or disposed of as per state and local guidelines.

CLEANING AND MAINTENANCE



CAUTION! Blades are sharp! Handle with care when cleaning.

- Switch off the appliance before cleaning and maintenance, never switch on the appliance during cleaning and maintenance.
- DO NOT submerge the chopping motor.
- Wash the blades immediately after use. To clean, rinse out the chopper while the cup is still attached. Add water and a small amount of dish washing liquid into the cup, operate the chopper for 10-20 seconds.
- You may further clean the blades by rinsing the blades under running water. Be careful not to wet the USB charging port.
- Fast Cleaning: Add appropriate amount of water to the cup. Hold down the power switch to start and operate for 5 to 10 seconds. Discard the water.

STORAGE

- Always store the product in a dry area.
- Protect the product from direct sunlight.

Made in China

KITCHENHQ

USB Mini Chopper INSTRUCTION MANUAL



Model: BM104032

3.7V/1200mAh/30W

Read this booklet thoroughly before using and save it for future reference.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

- Read all instructions before using.
- To protect against risk of electrical shock, do not put the motor unit in water or any liquid.
- Children should be supervised while using the appliance.
- Do not operate any appliance with a damaged cord, plug, after the appliance malfunctions, or is dropped or damaged in any manner.
- If the supply cord is damaged, it must be replaced by the manufacturer in order to avoid a hazard.
- Unplug the unit from the outlet before assembling or taking off parts and before cleaning. Unplug when not in use.
- Do not use attachments not recommended or sold by the manufacturer as it may lead to fire, electric shock, or injury.
- Always ensure the motor has stopped completely before disassembling.
- Do not insert your fingers into the chopper while it is in operation. If food becomes lodged in the chopper, turn chopper off and wait for motor to completely stop, then disassemble the chopper to remove ingredients.
- Do not put any parts except the cup into the dishwasher.
- Do not use appliance for other than intended purpose.
- Do not use appliance for more than 2 minutes continuously as the motor may burn out; do not use it again until the appliance is cooled down.
- Do not use the appliance to chop hard materials, including ice, frozen fruit, large seeds.
- Do not use an extension cord or timer with this appliance.
- Never disassemble the chop cup while the blade is running.
- Use caution as the stainless-steel blade is very sharp.
- Never press the chop button when the cup is removed or before assembling.
- Never use the appliance while recharging.
- Always add ingredients first before beginning to chop.

SAVE THESE INSTRUCTIONS

KNOW YOUR CHOPPER BEFORE FIRST USE

Check all the included components and ensure there is no damage before use. Remove all packaging materials used for protection during transportation. Clean the removable parts that come into contact with food with warm water.

PARTS:

What is included: (Note: Actual product may be different than shown.)

- Chopper with 1 Cup and Blade
- USB Charging Cable
- Instruction Manual



CHARGING

- For the first use, please fully charge your chopper, it may not have enough power to chop when you receive it.**
- The USB rechargeable port is on the motor. Plug in the supplied USB cable and plug its other end into a 5V/1A charging power source (e.g., charging adapter – not included).
- When pressing the power button red indicator light means the battery is low and needs to be charged. The red light is always on during charging and the indicator light is off after fully charged
- Note: One complete charge takes around 3.5 hours.

USING THE CHOPPER

- Cut the ingredients into about half inch chunks. If ingredients have thick skin or a hard shell, please remove the thick skin first.
- Install the blade ensuring circular end of the blade shaft goes in the post on the bottom of the cup.
- Add the food ensuring it is not above the blade level.
- Put the motorized power unit onto the cup along the two slots of the cup. When the motorized power unit is installed, the blue indicator light flashes three times. Never operate the machine before fixing the motor to the cup.
- Press the power button to start chopping. While you hold down the power button, the blades will chop the food. You can hold the power button for continuous chop, or you can push and release the power button for short chopping cycles.

Note:

- Do not overload the cup, otherwise the blades may not rotate when it is started.
- If the ingredients are stuck on the blade, shake the chopper slightly by hand. (Never touch the blade with hand)
- Switch off the chopper before taking off the cup, never switch it on after taking off the cup.