

IMPORTANT NOTICE

Please read operating instructions before using this product. Please keep original box and packing materials in the event that service is required.

For questions or concerns please contact customer service at:

Synergy Housewares, LLC.

Toll-free: 866-444-4033

Hours: M-F 9:00am-5:00pm EST

Website: warranty.synergyhousewares.com

Printed in China

Model SWPAF97

WOLFGANG PUCK /

USE AND CARE

**9.7 QT. RAPID-AIR
1700-WATT
AIR FRYER**



Actual product may differ slightly from images in this manual
Wolfgang Puck is a trademark of Wolfgang Puck Worldwide

Model SWPAF97

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- 1 Read all instructions.
- 2 Do not touch hot surfaces. Use handles or knobs.
- 3 To protect against electrical shock do not immerse cord, plug or housing in water or other liquid.
- 4 Close supervision is necessary when any appliance is used by or near children.
- 5 Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- 6 Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. For customer service please contact 866-444-4033.
- 7 The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- 8 Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 9 Do not use outdoors.
- 10 Do not let cord hang over edge of table or counter, or touch hot surfaces.
- 11 Do not place on or near a hot gas or electric burner, or in a heated oven.
- 12 Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- 13 Plug the cord into the wall outlet. To disconnect, turn timer knob to the 0 (off) position, then remove plug from wall outlet.
- 14 Do not use appliance for other than intended use.
- 15 Oversize foods or metal utensils must not be inserted in the appliance as they may create a fire or risk of electric shock.
- 16 A fire may occur if the appliance is covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation. Do not store any item on top of the appliance when in operation. Leave at least 5" free space on the back and sides and above the appliance while cooking.
- 17 Do not clean with metal scouring pads. Pieces can break off the pad and touch electrical parts, creating a risk of electric shock.
- 18 Extreme caution should be exercised when using containers constructed of other than metal or glass.

- 19 Do not store any materials, other than manufacturers recommended accessories in this appliance when not in use.
- 20 Do not place any of the following materials in the appliance: paper, cardboard, plastic, and the like.
- 21 Use extreme caution when removing the pan, or air frying rack and disposing hot grease.
- 22 Should dark smoke appear to be coming from the appliance immediately unplug. Wait for smoke to stop before pulling the pan out of appliance.
- 23 Do not leave appliance unattended while it is operating.
- 24 Hot air and steam will be released from the air outlet opening at the rear of the housing. Keep your hands and face away from the steam and air outlet openings. Never cover air outlet.
- 25 This appliance is not a deep fryer and should never be filled with fat or oil.
- 26 Never use this appliance without the pan and air frying rack in place.
- 27 Always remove crumbs and food particles from pan before cooking a second batch of food.

SAVE THESE INSTRUCTIONS HOUSEHOLD USE ONLY

Additional Safety Information

GROUNDING INSTRUCTIONS: This appliance must be grounded. It is equipped with a 3-prong cord having a grounded plug. The plug must be plugged into an outlet which is properly installed and grounded.

WARNING: Improper use of the grounded cord can result in the risk of electric shock. Consult a qualified electrician if necessary. Do not attempt to defeat this safety feature by modifying plug.

A short power-supply cord is provided to reduce the hazards resulting from entanglement or tripping over a long cord. If it is necessary to use an extension cord, it should be positioned such that it does not drape over the counter or tabletop where it can be pulled on by children or tripped over and:

- A. Use only 3-prong extension cord with 3-blade grounding plug.
- B. The marked rating of the extension cord must be equal to or greater than the rating of this appliance. The electrical rating of this appliance is 1,700 watts.





In the beginning, there was Wolfgang Puck. There were cooks and there were kitchens and there were people eating food, but the world had never seen anything like Spago—with its California cuisine, its casual elegance, and its chef whose genuine warmth and love of craft redefined the dining experience. And they came—from LA and from everywhere—to experience the future. Wolfgang Puck shaped the modern culinary landscape: he was the first celebrity chef, the inventor of fusion cuisine, the first in farm-to-table. His work is inspired by California living, and an insistence on only the freshest ingredients. From

his legendary fine dining icons, his entrepreneurial spirit has built an empire—from dining, to catering, to products for the home—touching the lives of millions around the globe. Today, as always, Chef Puck is earnestly, restlessly, tirelessly at work behind the scenes inventing what's next. He is driven by a genuine love of his craft, a passion for what's possible, and its potential to change the world.

Table of Contents


Important Safeguards	1
Additional Safety Information	2
About Wolfgang Puck	3
Know Your Air Fryer	5
Before Your First Use	6
Using Your Air Fryer	7
Care & Cleaning	8
Air Fryer Cooking Chart	9
Troubleshooting	11
Recipes	12
Limited Warranty	22
Contact Information	Back

Know Your Air Fryer



Actual product may differ slightly from illustrations in this manual

Know Your Air Fryer (Cont.)



Before Your First Use

- 1 Unpack the Air Fryer and remove all packaging materials. Clean the Air Fryer according to the Care & Cleaning section of this manual.
- 2 We recommend performing a trial run of your Air Fryer to eliminate any protective substance from the heating elements. Conduct the trial run in a well-ventilated area as a small amount of smoke and odor may be detected. This is normal and should be expected. Follow the procedure below for the trial run.
- 3 Place Air Fryer on a stable, level surface.
- 4 Place Air Frying Rack in the Pan and insert into Housing.
Note: This appliance is rated 1,700 watts and should be the only appliance operating on the circuit to avoid tripping your circuit breaker. Always ensure that your Timer/Power Knob is set to 0 (off) and your Temperature Knob is set to Off before plugging into the wall outlet
- 5 Plug the Air Fryer into the wall outlet.
- 6 Set the Temperature Dial to 400°F and the Timer Knob to 20 minutes.
- 7 Your trial run is complete once the set time has elapsed.

Using Your Air Fryer

Caution:

This Air Fryer works by circulating hot air via a convection fan. Do not fill the Pan with oil or frying fat.

- 1 Place the appliance on a flat, stable, level, heat-resistant surface.
- 2 Remove the Pan from the Housing by pulling the Handle towards you.
- 3 Place your ingredients on the Air Frying Rack in the Pan.

Note: Never use the Pan without the Air Frying Rack in place.

- 4 Place the Pan back into the Housing until it is completely flush with the Housing. If the Pan is not fully engaged into the Housing the Air Fryer will not turn on.

Note: This appliance is rated 1,700 watts and should be the only appliance operating on the circuit to avoid tripping your circuit breaker. Always ensure that your Timer/Power Knob is set to 0 (off) and your Temperature Knob is set to Off before plugging into the wall outlet.

- 5 Plug the Air Fryer into the wall outlet.
- 6 Turn the Temperature Knob to the desired temperature.
- 7 Turn the Timer Knob to the desired cooking time. The Power Indicator Light will illuminate and remain lit while Timer is engaged. The Heat Indicator Light will illuminate and will cycle on and off during cooking to ensure the set temperature is maintained. For recipe times greater than 60 minutes, reset the Timer Knob once the set time has elapsed.
- 8 The Timer Knob will automatically turn the appliance off when the set time has elapsed. You can manually turn the appliance off by turning the Timer Knob counter-clockwise to the 0 (off) position.
- 9 Some food types require rotating halfway through the cooking cycle, while other items such as French fries require shaking the Pan. See the Air Fryer Cooking Chart in this manual for recommended temperature, cooking times and method.
- 10 When the Timer has elapsed the signal bell will ring and the Air Fryer will turn off. Unplug the Air Fryer from the wall outlet. Remove the Pan from the Housing and place it on a heat-resistant surface such as a trivet. We recommended using tongs or other kitchen utensils to remove the food from the Pan.

Using Your Air Fryer (cont.)

Caution:

Both the Pan and Air Frying Rack are very hot after cooking, use caution when handling to avoid a burn injury, always use potholders or oven mitts.

When cooking foods greater than 3lbs **lift the Pan by the Handle and support the Pan on the rear using your other hand.** Always use potholders or oven mitts when handling the hot Pan.

Care & Cleaning

Your Air Fryer should be cleaned after each use. Residual food particles and grease can cause the Air Fryer to smoke excessively if not properly cleaned.

Turn the Timer Knob to the 0 (off) position and unplug from wall outlet. Allow all parts to completely cool before cleaning.

Pan and Air Frying Rack

No parts of the Air Fryer are dishwasher safe. Please follow the below cleaning instructions:

To avoid damaging the nonstick surfaces do not use metal utensils. Only use nylon or wooden utensils.

Remove the Air Frying Rack from the Pan. The Pan and Air Frying Rack are nonstick coated to allow for easier release of food residue. Do not clean with metal scouring pads as pieces can break off the pad and touch electrical parts, creating a risk of electric shock. Do not use abrasive cleaners.

Wash the Pan and Air Frying Rack with warm soapy water using a sponge or cleaning cloth. If food residue is hard to remove from Pan or Air Frying Rack, soak them for 10 minutes in warm, soapy water. Rinse and dry parts thoroughly before reassembling and storing.

Housing, Cord, and Plug

These parts should never be immersed in water or any other liquid. Only wipe these parts using a damp cloth then dry thoroughly.

Air Fryer Cooking Chart

Cooking times in the chart below represent total cooking time. If a cooking method is recommended for the ingredient it should be done half-way through the times below.

The cooking chart provides general guidelines and can be adjusted to suit your own personal taste.

Ingredient	Time (Minutes)	Temp. (°F)	Suggested Method
BEEF			
Burger, 4oz.	18-22	375°F	
Beef Tenderloin, 8 oz.	16-18	400°F	
London Broil, 2 lbs.	24-28	400°F	
Meatballs, 1-3 in	7-10	375°F	
Rib-eye, bone-in, 1-in, 8 oz.	12-16	400°F	
Sirloin Steak, 1-in, 12 oz.	10-14	400°F	
Beef Eye Round Roast, 4-5 lbs.	48-55	400°F	Flip
CHICKEN			
Breasts, boneless, 4 oz.	12-14	375°F	
Drumsticks, 2.5 lbs.	20-24	375°F	
Thighs, bone-in, 2 lbs.	22-24	375°F	
Wings, 2 lbs.	12-14	400°F	Shake
Whole Chicken, 5 lbs.	60	375°F	Flip
Tenders	8-10	375°F	Shake
FISH & SEAFOOD			
Calamari, 8 oz.	4-6	400°F	
Salmon Fillet, 6 oz.	12-14	375°F	
Tuna Steak	8-10	400°F	
Shrimp	4-6	400°F	
FROZEN FOODS			
Onion Rings, 12 oz.	8-10	400°F	
French Fries, cut thin, 20 oz.	12-14	400°F	Shake
French Fries, cut thick, 17 oz.	18-20	400°F	Shake
Mozzarella Sticks, 11 oz.	8-10	400°F	
Chicken Nuggets, 12 oz.	10-12	400°F	Shake

Air Fryer Cooking Chart (Cont.)

When cooking foods such as fresh potatoes we recommend spraying the food with an oil mister to give extra crispiness. Do not spray the food until you are ready to place the Pan in the Housing.

Never add oil or fat to the Pan for shallow or deep frying. This Air Fryer is designed to cook via convection air. Placing oil into the Pan can cause splattering of oil into the heating elements and poses a fire risk.

Ingredient	Time (Minutes)	Temp. (°F)	Suggested Method
LAMB			
Lamb Chops, 1-in thick	10-12	400°F	
Rack of Lamb, 2 lbs.	22-26	375°F	
PORK			
Pork Loin, 2.5 lbs.	55-60	350°F	
Pork Chops, bone-in, 1-in	12-14	400°F	
VEGETABLES			
Asparagus	5-6	400°F	
Broccoli Florets	6-8	400°F	
Carrots	14-16	375°F	
Corn on the Cob	6-8	400°F	
Eggplant, 1.5-in pieces	14-16	400°F	
Green Beans	4-6	400°F	
Mushrooms, 1/4-in slices	4-6	400°F	
Peppers, 1-in pieces	14-16	400°F	
Potatoes, 1-in pieces	12-14	400°F	
Potatoes, Whole	38-42	400°F	
Sweet Potatoes, baked	32-36	375°F	
Zucchini, 1/2-in pieces	12-14	400°F	

Troubleshooting

Problem	Cause	Solution
The Air Fryer has no power	The appliance is not plugged in.	Plug power cord into wall socket.
	You have not turned on the Timer.	Set the Timer to desired cooking time, the Timer controls the power to the Air Fryer.
Food is not cooked properly	The Pan is overloaded.	Use smaller amounts of food, spread evenly throughout the Pan.
	The temperature is set too low.	Ensure you are using the correct temperature for the recipe, or reference the Air Fryer Cooking Chart on pages 9 & 10 of this manual.
Food is not fried evenly	Some foods need to be shaken or flipped during the cooking process.	See Air Fryer Cooking Chart on pages 9 & 10 of this manual.
White smoke coming from unit	Oil is dripping into Pan.	Excess oil from fatty foods had dripped into the Pan and is causing the smoking. This is normal.
	Pan or Air Frying Rack has grease residue from previous cooking.	Clean the Pan and Air Frying Rack after each use.
French fries are not fried evenly	Potatoes are not fresh, too soft.	Use fresh, firm potatoes.
	Potatoes are not rinsed properly during preparation.	Rinse and pat dry to remove excess starch.
Fries are not crispy	Raw fries have too much water, starch, or are cut too thick.	Rinse and pat dry cut potatoes to remove excess starch
		Use smaller cut fries.
		Mist or spray a small amount of oil on fries

Recipes

Miso Salmon

2 servings

INGREDIENTS

2 salmon fillets
2 tablespoons light miso paste

METHOD

1. Spread both sides of salmon fillets with miso paste.
2. Place salmon into the air fryer.
3. Set temperature to 400°F and timer to 10 minutes.
4. Air fry for 5 minutes then turn over and cook for an additional 5 minutes or until salmon flakes easily.
5. When cooking is complete, transfer to a serving plate.
6. Garnish as desired and serve.

Easy Pimento Chicken Tenders

2 servings

INGREDIENTS

8 raw chicken tenders
2 tablespoons panko bread crumbs
Spray olive oil, kosher salt and fresh pepper to taste
8 strips pimento peppers, from a jar
1/4 cup plain Greek yogurt, for dipping

METHOD

1. Place chicken, panko, spritzes of oil, salt and pepper into a plastic zip top bag; shake to coat.
2. Transfer chicken to the air fryer then top each tender with a strip of pimento.
3. Set temperature to 400°F and timer to 12 minutes.
4. Air fry for 6 minutes then toss and continue to cook for an additional 6 minutes or until chicken is just cooked through.
5. When cooking is complete, transfer to a serving plate.
6. Garnish as desired and serve with yogurt for dipping.

Easy French Fries

1 serving

INGREDIENTS

1 large Russet potato
Spray oil and kosher salt to taste

METHOD

1. Cut potato into long, thin fries.
2. Spritz with oil then sprinkle with salt.
3. Place potatoes into the air fryer.
4. Set temperature to 375°F and timer to 20 minutes.
5. Air fry for 10 minutes then toss and cook for an additional 10 minutes or until brown.
6. When cooking is complete, transfer to a serving plate.
7. Garnish as desired and serve.

Italian Chicken Wings

2-4 servings

INGREDIENTS

12 chicken wing drumettes and flats
Spray olive oil
1 package dry Italian dressing mix, to taste

METHOD

1. Place wings, a few spritzes of oil and Italian dressing mix into a plastic zip top bag; shake bag to coat.
2. Transfer wings to the air fryer.
3. Set temperature to 400°F and timer to 24 minutes.
4. Air fry for 12 minutes then toss wings and cook for an additional 12 minutes or until well browned and cooked through.
5. When cooking is complete, transfer to a serving plate.
6. Garnish as desired and serve.

Crustless Quiche

4 servings

INGREDIENTS

2 large egg whites
4 large eggs, beaten
1 cup Brussels sprouts or spinach, shaved
3 tablespoons unsalted butter, melted
2 tablespoons chiffonade of prosciutto
1/4 cup cottage cheese
Kosher salt and fresh pepper to taste

METHOD

1. Using a hand mixer, whip all ingredients together until foamy.
2. Divide mixture between 4 large ramekins.
3. Place ramekins into the air fryer.
4. Set temperature to 250°F and timer to 20 minutes.
5. Air fry for 10 minutes then turn and cook for an additional 10 minutes or until eggs are just set.
6. When cooking is complete, transfer to a serving plate.
7. Garnish as desired and serve.

Appetizer Orange Camembert

6 servings

INGREDIENTS

1 small camembert cheese
1 package (17.1 ounces) puff pastry, thawed
1/4 cup orange marmalade
1 tablespoon turbinado sugar
Crackers and apple wedges, for serving

METHOD

1. Place the whole cheese in the center of the puff pastry.
2. Spread marmalade over the cheese.
3. Place pastry into the air fryer.
4. Fold puff pastry over the cheese to form a square package.
5. Crimp to seal then sprinkle with sugar.
6. Set temperature to 325°F and timer to 30 minutes.
7. Air fry for 15 minutes then turn and cook for an additional 15 minutes or until puffed and well browned.
8. When cooking is complete, transfer to a serving plate.
9. Garnish as desired and serve with crackers and apple wedges.

Baked Pears

2 servings

INGREDIENTS

2 firm pears
4 prunes, chopped
1/4 teaspoon ground nutmeg

METHOD

1. Using a melon baller, remove each pear's core without cutting all the way through.
2. Stuff cavities with prunes then sprinkle with nutmeg.
3. Transfer pears to the air fryer.
4. Set temperature to 350°F and timer to 20 minutes.
5. Air fry for 20 minutes or until well browned and soft.
6. When cooking is complete, transfer to a serving plate.
7. Garnish as desired and serve.

Mexican Fiesta Salad

2-4 servings

INGREDIENTS

1 jalapeño pepper, minced
Zest and juice of 1 lime
1 tablespoon cilantro, chopped
Spray oil, kosher salt and fresh pepper to taste
4 fillets mild white fish
8 cups spring mix lettuces
Ranch dressing, for serving

METHOD

1. Place the jalapeño, lime and cilantro into a plastic zip top bag.
2. Add the fish, a few spritzes of oil, salt and pepper; shake to coat.
3. Transfer fish to the air fryer.
4. Set temperature to 400°F and timer to 10 minutes.
5. Air fry for 5 minutes then turn and cook for an additional 5 minutes or until fish flakes easily.
6. When cooking is complete, transfer to a top of salad greens.
7. Garnish as desired and serve with dressing.

Extra Lean Bison Patty

2 servings

INGREDIENTS

10 ounces lean ground bison
1/4 cup red bell pepper, diced
1 cup spinach, chopped
1/4 teaspoon dried sage
Kosher salt and fresh pepper to taste

METHOD

1. In a bowl, combine all ingredients then shape mixture into 2 patties.
2. Place patties into the air fryer.
3. Set temperature to 400°F and timer to 14 minutes.
4. Air fry for 7 minutes then turn and cook for an additional 7 minutes or until internal temperature reaches 165°F on a meat thermometer.
5. When cooking is complete, transfer to a serving plate.
6. Garnish as desired and serve.

Cheesy Bread

2 servings

INGREDIENTS

2 tablespoons unsalted butter, melted
1 hoagie roll, cut in half lengthwise
1/2 cup Parmesan cheese, grated
2 sprigs rosemary

METHOD

1. Spread butter over bread then top with cheese and rosemary sprig.
2. Place bread into the air fryer.
3. Set temperature to 325°F and timer to 10 minutes.
4. Air fry for 5 minutes then turn and continue to cook for an additional 5 minutes or until brown.
5. When cooking is complete, transfer to a serving plate.
6. Garnish as desired and serve.

Limited Warranty

This warranty covers all defects in workmanship or materials in the mechanical and electrical parts, arising under normal usage and care, in this product for a period of 12 months from the date of purchase provided you are able to present a valid proof-of-purchase. A valid proof-of-purchase is a receipt specifying item, date purchased, and cost of item. A gift receipt with date of purchase and item is also an acceptable proof-of-purchase. Product is intended for household use only. Any commercial use voids the warranty.

This warranty covers the original retail purchaser or gift recipient. During the applicable warranty period within normal household use, we will repair or replace, at our discretion, any mechanical or electrical part which proves defective, or replace unit with a comparable model.

To obtain service under the terms of this warranty, call Toll Free (866) 444-4033.

THIS LIMITED WARRANTY COVERS UNITS PURCHASED AND USED WITHIN THE UNITED STATES AND CANADA AND DOES NOT COVER:

- Damages from improper installation.
- Defects other than manufacturing defects.
- Damages from misuse, abuse, accident, alteration, lack of proper care and maintenance, or incorrect current or voltage.
- Damage from service by other than an authorized dealer or service center.

This warranty gives you special legal rights and you may also have other rights to which you are entitled which may vary from state (province) to state (province).

Proof of purchase required to validate the warranty.

Shipping and handling charges may apply.