95mm

145mm

Oscillating Handheld Fan

User Manual

Model: WT-F69

IMPORTANT: Read the instructions carefully before operating the fan and keep them for future reference.

TABLE OF CONTENTS

WARNING ——— Page 2
FCC WARNING ——— Page 3
PRODUCT SPECIFICATION ——— Page 4
HOW TO USE ——— Page 5
LIMITED WARRANTY ——— Page 6

WARNING

1. Make sure the mains voltage is consistent before using (DC 5V).
2. To avoid electric shock, any user connection must not water.
3. Do not touch the mains water.
4. Please do not give the elderly people, babies or people with reduced mobility a child access to using, this is to avoid accidents.
5. Please do not put the fan on a hot heat source, as a high-temperature place to prevent damage to the product.
6. Do not use the product if the power fan is faulty, abnormal, twisted or any other failures, once they may be broken into the fan, damage the motor and even cause a fire.
7. When the child is not present or found to be damaged or unsafe, please stop using and contact the repair center and do not disassemble and repair, do not maintain it by yourself.
8. Unplug the USB cord from the plug before cleaning, repairing or moving the product.
9. When the fan is not used for a long time, please charge the battery completely and then store in a dry place, please unplug the power cord to avoid electrical safety hazards like after a long time standby and cause accident or danger.
10. The product is not intended for children use. Please closely observe when in use by children the product.
11. There is also invisible heat, clean and regularly maintained.
12. Do not let the people refer to with disabilities, mental disabilities and lack of experience and knowledge of products including children, unless the product alone, if it is needed to use, it should be under the supervision of responsible adults.
13. Do not disassemble the fan by yourself to avoid causing personal injury and electric shock.
14. Do not let your fingers and other body parts or objects into the air inlet to avoid injury and other unnecessary damage or accidents.
15. Do not put with heavily pressure objects on the product to avoid damage and electric shock.
16. Unplug the power cord when cleaning the product to avoid accidental electric shock.
17. Before removing the protective cover, make sure that the fan is disconnected from the power supply to avoid accidental touch of the battery, what to do in the event of water on the shell.
18. Unplug the USB cable when the fan has been fully recharged.
19. If using head access during charging, stop charging so as not to produce and contact the customer service center.

To Protect The Environment

Recycling materials is beginning in accordance with local laws governing waste. By recycling and reusing, materials are returned back to our environment for protection.

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Importer: Silver Spring Home Tech Inc.
Address: 11 Gervais Dr. Suite 202, Dorval, Quebec, H9P1Y2
Email: service@silverspring.ca

PRODUCT SPECIFICATION



TECHNICAL SPECIFICATIONS

Model No.: WT-F69
Rated Input Power: 5V ⎓ 1.5A
Max Voltage: 5V ⎓
Max Current: 1.5A (max)
Rated Power: 7.5W
Product Dimensions: 4.33" x 2.95" x 10.04"
Working Time: 1 ~ 3 hours
Recharge Time: 4 hours
Connector: Micro
Oscillation Head Angle: 90°
Fan Material: ABS
Cord Type: 1.1
Fan Type: Charging Type 1

HOW TO USE

INSTRUCTION

- Charging: Before the initial use of the fan, it is necessary to charge it for more than the two-speed levels. There are four speed settings in total. Charging time you will take more than 4 hours.
- When the fan is running, press the "Low" or "Low" button, the corresponding indicator button is light indication. The fan will operate and start. Press and hold the button to turn off the fan.

(If the Power Cable is not plugged in, the oscillation button will not function.)

- When you want to oscillate the fan, please press oscillation button and desired speed.
- If the oscillation is caused or in the process of oscillating, please press the oscillation button to restore the fan to a stationary state.

INDICATOR AND BATTERY STATUS DESCRIPTION

While charging, the battery indicator shows the current battery level:

- Battery level 25% ~ 50%: the first light is on, and the second light flashes.
- Battery level 50% ~ 75%: the first and second lights are on, and the third light flashes.
- Battery level 75% ~ 100%: the first, second and third lights are on, and the fourth light flashes.
- When fully charged, all four lights are on.

When the fan is discharging, the battery indicator shows the current battery level:

- Battery level 75% ~ 100%: the first, second, third and fourth lights are on.
- Battery level 50% ~ 75%: the first, second and third lights are on.
- Battery level 25% ~ 50%: the first and second lights are on.
- Battery level 10% ~ 25%: the first and second lights are on, and the fourth light flashes.
- Battery level below 10%: the first light flashes.

Cleaning and Maintenance

- Clean the blades using the protein before cleaning, maintaining, or moving it.
- Clean the surface of the fan with a soft, slightly damp cloth.

Note

- **do not** insert objects in the fan has something stopped.
- **do not** immerse the product in a cleaner, use in water. Direct cleaning with water is not allowed.
- The internal parts of the fan **must not** come into contact with water.
- **do not** use detergents, wire brushes, detergents, abrasives, or gasoline or other volatile or corrosive liquids to clean the product.

Allow the fan to air dry, and use a piece of multi-purpose cloth to wipe away excess water.

LIMITED WARRANTY

Silver Spring Home Tech Inc. warrants to the original consumer or purchaser that this Oscillating Handheld Fan is free from defects in materials and workmanship to be operated at **one (1) year** from the date of purchase. If such a defect is discovered within the warranty period, return the complete fan to Inc., date, shipped, on repair or replace the product at no cost. Remember any warranty service by the original purchaser or authorized service center listed below.

For warranty or repair service, please email **service@silverspring.ca.**

Please include your product's model number, your name, and the date and location of purchase.

No Other Warranty

No other warranty applies to this product. This warranty is in lieu of any other warranty express or implied, including without limitation, any implied warranty of merchantability or fitness for a particular purpose. To the extent any implied warranty is required by law, it is limited in duration to the express warranty period stated herein. Silver Spring Home Tech Inc. nor its U.S. distributor shall be liable for any incidental, consequential, indirect, special, or punitive damages of any kind or nature, including but without limitation, lost revenues or profits, or any other damages whether based in contract, tort, or otherwise. Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

THIS LIMITED WARRANTY DOES NOT APPLY TO:

- Damage to the product caused by accident, misuse, interruptions, or inadequate electrical service.
- Damage caused by transportation, shipping or improper handling.
- Damage caused by accident, abuse, lightning, storm fire, flood, or other acts of God.
- Damage resulting from accident, alteration, misuse, abuse, improper maintenance, repair or modification by anyone other than a dealer or service center that is authorized by Silver Spring Home Tech Inc.
- Consumables or product modification, repair by unauthorized service centers, or use of non-approved accessories or parts.
- Incidental damage or unauthorized disclosure to the user as a result.