

Quick Start Guide

Scan with your **Camera** app for the video and the *User Guide*.



HQ62201004110-A

Copyright & trademarks

MOTOROLA, the stylized M logo, MOTO, and the MOTO family of marks are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. Google, Android, Google Play and other related marks and logos are trademarks of Google LLC. USB Type-C* and USB-C* are registered trademarks of USB Implementers Forum. All other product or service names are the property of their respective owners.

© 2024 Motorola Mobility LLC. All rights reserved.


Product ID: moto g 5G - 2024 (Model XT2417D)

Set up your phone

Charge your phone, then press and hold the Power button until your phone display lights up. Follow the prompts to get started.



Charger/USB Port



Power/Lock Button

Press: Display on/off. Press & hold: Phone on.

Tip: To turn off your phone, press the Power and Volume Up buttons at the same time.

Note: Before using your phone, please read the legal, safety, and regulatory information provided with your product. For the complete legal information, from the home screen, swipe up and tap **Settings** > **Q**, then type **Legal information**, or visit www.motorola.com/device-legal.

Sign in or create a Google account

If you use Gmail™, you already have a Google™ account—if not, you can create an account during setup.

Signing into your Google account lets you access, sync, and backup your stuff. You can see your Google apps, contacts, calendar, photos, and more.


- To add, edit, or delete accounts, from the home screen, swipe up and tap Settings > Passwords & accounts.
- $\bullet \ \, \text{For help with your Google account, visit} \ \underline{\text{www.google.com/accounts}}.$

Discover Moto

Get helpful tips, personalize your phone, and set custom features, like touching and holding the screen with three fingers to take a screenshot, turning on the flashlight with two chopping motions, and twisting your wrist twice quickly to open the camera. From the home screen, swipe up and tap the **Moto** folder > Moto.

Lock/unlock your screen

Your screen locks automatically when you are not using it.



- Screen off/on: Press the Power button.
- Secure your phone: From the home screen, swipe up and tap
 Settings > Security & privacy > Device unlock, and tap Screen lock, Fingerprint, or Face Unlock.
- Customize lock screen: Add a text message to your lock screen, choose how notifications are displayed on the lock screen, set gesture to wake up the screen or turn it off, and more. From the home screen, swipe up and tap Settings > Home & lock screen > Lock screen.

Make and answer calls

From the home screen, tap C Phone.

- Answer a call: When your phone is locked, swipe up to answer.
 When the phone is unlocked, tap Answer.
- Import contacts: Your contacts are imported when you sign into your Google account. If this didn't happen automatically, from the home screen, swipe up and tap Contacts > Fix & manage > Settings > Accounts > Automatically sync app data.

Set up your voicemail

When you have new voicemail, ∞ appears in the status bar. To hear it, swipe down and tap the notification.

To set up your voicemail, follow these steps:

- 1 From the home screen, tap (Phone.
- 2 Tap 🕮 to open the dialpad.
- 3 Touch and hold 1.

Your phone will automatically call Voicemail. Once the call is connected, follow the voicemail setup prompts.

4 Tap 📀 to end the call.

Send messages

From the home screen, tap (Messages.



- Create: Tap Start chat
- Attach: When you're typing a message:
- Tap (+) to attach an emoji or a file, share your location, and more.
- Touch and hold \mathbf{Q} to create a voice recording.
- Tap 🚯 to attach a photo or a video.
- Send: Tap or to send the message.

Use your Mobile Internet

Access the web

To access the Internet with the Chrome browser app, tap **© Chrome**.

Connect to Wi-Fi networks

To turn Wi-Fi on, swipe the status bar down. Touch and hold **▽**; **Wi-Fi**, turn on **Wi-Fi**, and then choose a Wi-Fi network.

To find networks in range:

- 1 From the home screen, swipe up and tap Settings > Network & internet > Wi-Fi.
- 2 With Wi-Fi turned on, tap a found network to connect to it. When connected, you'll see ▼ in the status bar.

Note: If you see a question mark in the Wi-Fi status indicator , swipe the status bar down, tap the network, and enter the network's password. It is recommended you connect to a secure private network as public networks without passwords may not be safe.

Enable Mobile Data

Your phone uses your Wi-Fi network to access the Internet. When a Wi-Fi network is not available, you can use your mobile phone network. Mobile data is on by default. To turn it off, swipe the status bar down and tap 1, * Mobile data.

Note: 5G service plan and 5G network coverage required; available only in select areas; device not compatible with all 5G networks. Contact your service provider for details.

Connect with Bluetooth wireless

Turn Bluetooth on

To turn Bluetooth on, swipe the status bar down and tap *** Bluetooth**. Touch and hold it to open Bluetooth settings.

Note: Your phone automatically turns on Bluetooth when you connect to a paired device.

Connect devices

The first time you connect a Bluetooth device, follow these steps:

- **1** Make sure the device you are pairing with is in discoverable mode.
- 2 From the home screen, swipe up and tap Settings > Connected devices > Pair new device.
- **3** With Bluetooth turned on, tap a found device to connect it (if necessary, tap **Pair** or enter a passkey like **0000**).

To automatically disconnect or reconnect a device, just turn the device off or on.

Note: Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely.

Notifications and quick settings

Swipe the status bar down to see your notifications. For quick access to **Flashlight**, **Airplane mode**, brightness, and other settings, swipe down twice.

Legal information

Operational warnings. Obey all local restrictions when using mobile devices in public areas, such as hospitals, airplanes, or schools.

- Potentially explosive areas: Potentially explosive areas are often, but not always, posted and can include
 blasting areas, fueling stations, fueling areas (such as below decks on boats), fuel or chemical transfer or
 storage facilities, or areas where the air contains chemicals or particles, such as grain dust, or metal powders.
 Turn off your phone before entering such an area, and do not charge batteries. In such areas, sparks can occur
 and cause an explosion or fire.
- Symbol key: Your charger, phone, battery (if user-removable), phone display, user's guide, or packaging may contain symbols, defined as follows:



Water repellent. Your phone is not waterproof. For more about your phone's water-repellent design and care, swipe up and tap Settings > Help.

Charging and battery safety. To prevent possible burning and injury, the battery in your phone should only be removed by a Motorola-approved service center or similar skilled personnel.

If your phone becomes unresponsive, press and hold the Power button until the screen goes dark and your phone restarts. Charge your phone using a compatible Motorola charger (may be sold separately). Use of other chargers is not recommended and may impair the charging performance. Don't charge your phone in temperatures below $-20^{\circ}\mathrm{C}$ (-4°F) or above 45°C (13°F). Chargers that do not comply with applicable national standards may be unsafe, with risk of death or injury, and may cause slow charging or product damage. To view applicable standards and to learn more, see the "Legal information" section of this guide, or visit www.motorola.com/device-legal.

Extreme heat or cold. Don't use your phone in temperatures below -20°C (-4°F) or above 45°C (113°F). Don't store/transport your phone in temperatures below -20°C (-4°F) or above 60°C (140°F).



