

CARE & CLEANING

- 1 Before cleaning, always unplug 3-in-1 Grill Griddle from outlet. Allow the product to cool down completely before cleaning.
- 2 Always clean Grill/Griddle Plates after each use. Grill/Griddle Plates can be washed in warm, soapy water, or placed in dishwasher.
- 3 Remove Drip Tray and discard contents before cleaning. Drip Tray can be washed in warm, soapy water, or placed in the dishwasher.
- 4 To clean Housing, wipe down with a damp cloth and dry thoroughly after every use. Never submerge in water or other liquids.
- 5 Do not place Housing in the dishwasher, this will damage internal components.
- 6 To clean Splash Guards, wipe with a damp cloth and dry thoroughly after each use.
- 7 Never use harsh chemical detergents, powders, or scouring pads on the Dura-Pan® non-stick surface or any other parts of 3-in-1 Grill Griddle.
- 8 Use nylon or wooden utensils to remove food from 3-in-1 Grill Griddle. Do not use metal utensils to avoid damaging the Dura-Pan® non-stick surface.
- 9 Store product in a clean, dry place.
- 10 Contact Customer Service for any issues or malfunctions.

1 YEAR LIMITED WARRANTY

This warranty covers all defects in workmanship or materials in the mechanical and electrical parts, arising under normal usage and care, for this product for a period of 12 months from the date of purchase provided you are able to present a valid proof-of-purchase. A valid proof of purchase is a receipt specifying item, date purchased, and cost of item. A gift receipt with date of purchase and item is also an acceptable proof-of-purchase. Product is intended for household use only. Any commercial use voids the warranty.

This warranty covers the original retail purchaser or gift recipient. During the applicable warranty period within normal household use, we will repair or replace, at our discretion, any mechanical or electrical part which proves defective, or replace unit with a comparable model.

THIS LIMITED WARRANTY COVERS UNITS PURCHASED AND USED WITHIN THE UNITED STATES AND CANADA AND DOES NOT COVER:

- Damages from improper installation.
- Defects other than manufacturing defects.
- Damages from misuse, abuse, accident, alteration, lack of proper care and maintenance, or incorrect current or voltage.
- Damage from service by other than an authorized dealer or service center.
- This warranty gives you special legal rights and you may also have other rights to which you are entitled which may vary from state (province) to state (province).
- Shipping and handling charges may apply.
- Proof of purchase is required to confirm the warranty.

CURTIS STONE PRODUCTS CUSTOMER SERVICE INFORMATION

EMAIL	product@curtisstone.com
TOLL-FREE PHONE	1.877.822.7450
HOURS	M-F 8:00am – 4pm CT
WARRANTY SITE	https://warranty.curtisstone.com/ Visit our warranty site to register your Curtis Stone Products.

Dura-Pan® is a registered trademark of FoodFight Ltd. • Made in China

This product contains intentionally added:
NONSTICK PROPERTIES
 Perfluoroalkoxy Alkane Polymer (PFA) [CAS# 26655-00-5]
 Polytetrafluoroethylene (PTFE) [CAS# 9002-84-0]
 Fluorinated Ethylene & Propylene (FEP) [CAS# 25067-11-2]
 For more information about the chemicals in this product,
 visit www.foodfight.hk/ab1200pdf

Este producto contiene añadido intencionalmente:
PROPIEDADES ANTIADHERENTES
 Polímero de perfluoroalcoxi alcano (PFA) [CAS# 26655-00-5]
 Politetrafluoroetileno (PTFE) [CAS# 9002-84-0]
 Etileno fluorado y propileno (FEP) [CAS# 25067-11-2]
 Para obtener más información sobre los productos
 químicos de este producto, visite www.foodfight.hk/ab1200pdf



visit www.foodfight.hk/ab1200pdf