


LOOK

To get the best results from your new antenna, please follow these instructions

1

FIRST connect the micro USB connector to the Power Inserter. THEN connect the included power adapter into any standard 120V wall outlet.


PRIMERO conecte el cable micro USB al insertor de potencia. DESPUÉS conecte el adaptador de corriente incluido a cualquier tomacorriente de pared estándar de 120V.



2

Then connect the coaxial cable attached to the ANTENNA IN connector at the back of the TV or set-top box.

Conecte el cable coaxial incluyendo la funda de plástico (tapa) al conector ANTENNA IN en la parte trasera de la TV o Set-top box.



3

This antenna has a unique Signal Level Indicator, which clearly shows the current strength of incoming TV signals. The more LEDs lighting up, the stronger the signal. **PLEASE NOTE: You may live in a weak signal area where the incoming signals are not at full strength so not every LED will light up, however it may still be sufficient to receive channels in good quality.**

Esta antena cuenta con un Indicador de nivel de señal, el cual muestra claramente la intensidad actual de las señales de TV entrantes. Cuantos más LEDs se iluminen, más fuerte será la señal. **FAVOR DE TOMAR EN CUENTA: Puede vivir en un área de señal débil en donde las señales entrantes no tengan la suficiente intensidad por lo que no todos los LEDs se iluminarán, sin embargo, puede ser suficiente para la recepción de canales en buena calidad.**



Use Assistant App for Ideal Antenna Placement

IMPORTANT!

RUN Your TV's Channel Scan – Normally in Settings Menu


4

Decide how you would like to position the antenna:


a **STANDING UPRIGHT, WALL MOUNTED or FLAT.**

When you choose for STANDING UP, please use the included 2 stands and insert it into the 2 slots on the bottom of the rear of the antenna. When mounting to an interior wall, you have to drill 2 holes in your wall whereas the distance between the center of the holes should be 178 mm (7 inches). Put the plugs in the holes and put the screws in the plugs. We do suggest you to FIRST finalize this set up before drilling holes, since you might need to re-position the antenna for best reception.

Position the antenna as high as possible and move close to or in a window and facing the direction of the TV towers for best reception.



TURN THE ANTENNA SLIGHTLY FOR BETTER SIGNAL STRENGTH OR RECEPTION QUALITY - www.oneforall.com/support/antennas




5

IMPORTANT! - FINAL STEP

Now you can perform a channel scan on your TV. Set the **tuner mode** of the TV to **ANTENNA** first, then choose **CHANNEL SCAN** (may be called **AUTO PROGRAM**, **AUTO TUNING**, **AUTO SCAN** or **CHANNEL SEARCH** in the setup menu of your TV).

If the number of channels or the quality is poor, please change the antenna's position and repeat step **a** + **b** + **c** and RE-SCAN on your TV.



Download the FREE antenna setup App



Available on the App Store

ANDROID APP ON Google play

www.oneforall.com/assistantapp

WWW.ONEFORALL.COM/TIPS-AND-TRICKS
Before returning this product please call us for support

Antes de regresar este producto, llámenos para poder ayudarle

Customer Support: 855-823-3422 (toll free)

www.oneforall.com

RDN1160523