



Folding Garden Shovel



Use and Care Instructions

Uses:

- Can be used as a shovel to dig holes or as a hoe to dig trenches.
- The serrated edge can be used to cut through tree roots and small branches.

How to Use the Folding Shovel

Step 1

Remove it from the decorative pouch:



Step 2

Unfold the handle 180 degrees:





Step 3

Unfold the head 90 degrees and tighten the thread lock down to serve as a hoe:



90 DEGREE

Step 4

Unfold the head 180 degrees and tighten the thread lock to use it as a shovel tool:



180 DEGREE

Step 5

Shovel head features a sharp saw tooth edge to help you easily cut small branches:



Step 6

To fold the shovel up for storage, loosen the thread lock, and fold both the handle and head towards the center:



Care and Cleaning

- Recommend cleaning any debris off the shovel blade before putting it away.
- If you clean with water, make sure to dry before storing.

