

Fill Order



5 Finish with ice or frozen ingredients.

*If using more frozen ingredients, add more liquid.

4 Then add dry or sticky ingredients like seeds, protein powders, and nut butters.

3 Then add leafy greens.

2 Next add fresh fruits.

1 Start by adding liquid to or above the **MIN LIQUID** line.



Get to Know Your

NINJA BLAST™ MAX



Scan for additional recipes,
how-to-videos, and more.



For best results, **fully charge** blender (up to 3 hours) before first use.



MAX PORTABILITY

Twist and go vessel provides MAX PORTABILITY for on the go!



BLEND PROGRAMS

BLEND: (30 second manual mode) for protein shakes

AUTO-iQ® brings pre-programmed pulses and pauses to blend through tough ingredients.

SMOOTHIE: For fresh and frozen fruit smoothies

CRUSH: For frozen drinks



SMOOTHIE TOO THICK AND NOT BLENDING?

Stop blend program, add 1 tbsp. to 1/4 cup of liquid, then press BLEND until your smoothie comes together



or SHAKE vessel between blends to move ingredients.

NOTE: Stop the blend mode at any time by pressing the program button again.



3 WAYS TO CLEAN

DO NOT expose the motor base to any liquid.

QUICK CLEAN: Remove vessel and fill with 6 oz. of water and a drop of dish soap. Install the lid, install vessel, and blend for a few seconds.

HAND-WASH: Remove vessel and use a long-stemmed dish washing utensil to clean the blades.

DISHWASHER: Remove vessel and place it and lid on the top rack of the dishwasher.

BC250SERIES_INSRT_TIPSTRICKS_MP_MV5_240613