

LORNA MASEKO

MINI MULTICOOKER



INSTRUCTION MANUAL

Model:DRC-1.5E025

Read this booklet thoroughly before using and save it for future reference.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should be followed as follows:

- Read all instructions.
- Do not use for anything other than intended use.
- Do not place the unit on or near gas or another hot environment to avoid damages.
- Use extreme caution when moving the unit.
- Do not use near an open flame or cook top.
- Never place food or liquids directly into the Wonder Pot without first inserting the inner pot.
- Place the unit on a level surface away from walls and cupboards . Do not let the cord hang over the edge of a table or counter or touch hot surfaces.
- Do not immerse the unit in liquid or allow liquid to be in contact with electrical parts.
- Do not let children operate the unit.
- Do not touch the control panel with any sharp instruments.
- Do not block the air vent during cooking.
- To avoid scalding, never open the lid or put your hands or face close to the steam vent while in operation.
- Do not touch the inner pot during or directly after cooking as it will be extremely hot.
- Rice should not be rinsed in the inner pot as the non-stick coating of the inner pot can be damaged.

- Unplug unit from outlet before cleaning and allow to cool before cleaning, clean after every use.
- Do not use unit with an extension cord, always plug into a wall outlet.
- To prevent electrical shock do not immerse cord, plugs, or appliance in water or other liquid.
- Do not use the unit if the cord is damaged.
- Do not use outdoors.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries or damage to the unit.
- Always attach the cord to appliance, then plug the cord into a wall outlet. To disconnect remove plug from wall outlet.
- Make sure to clean the detachable lid and steam vent after each use.
- **SAVE THESE INSTRUCTIONS.**

BEFORE FIRST USE

1. Remove all packaging materials, stickers, and labels.
2. Clean the inner pot with hot water, dishwashing liquid, and a non-abrasive sponge.
3. Wipe the inside and outside of the appliance with a cloth.

USING THE APPLIANCE

Plug the cord into the unit and then the wall socket.

Warm/Cancel:

Throughout cooking if you wish to stop the cooking process press the cancel button. The display will display 00. During the standby mode pressing the warm/cancel button will put the unit into a 3 hour keep warm cycle.

Delay:

The delay button can be used on both rice and grain. Press the delay button and the unit will show the default time of 2 hours. Press the delay button again to change the time. This can be adjusted from 2 hours to 12 hours. After the desired delayed time is selected press either the rice or grain button dependent upon what is in the unit. When one hour is left on the delay time the unit will begin to countdown and then will automatically start cooking after this.

Rice:

Use the rice measuring cup included to put your rice in the inner pot.

Note: This is not a standard US 1 cup. Then fill with water to the line that correlates to how many cups of rice you put in the inner pot. For example if you put 1 measuring cup of rice in you would fill to the rice line on the inner pot labeled 1 cup. Press the rice button, after 5 seconds the unit will begin to cook. When there is 5 minutes left in the cooking cycle the screen will display 5 minutes on the screen. Once it is finished the unit will beep 5 times and the rice will be done cooking. The unit will switch to the keep warm for up to 3 hours. Press the button to unlock the lid, lift by the sides to open. The lid will rest on the unit. The unit will be extremely hot when opening, use caution. **Note:** In keep warm food will continue to cook so it is important to cancel or unplug the unit to avoid food burning.

Grain:


The inner pot has markings for quinoa and oats. Use the rice measuring cup included to put your grain in the inner pot. **Note:** This is not a standard US 1 cup. Then fill with water to the line that correlates to how many cups of grains you put in the inner pot. Press the grain button and select the desired time, the time can be adjusted from 10 to 50 minutes in 5 minute increments. Once desired time is selected the unit will automatically begin cooking. Once the unit begins to boil it will start to count down. The unit will switch to the keep warm for up to 3 hours. Press the button to unlock the lid, lift by the sides to open. The lid will rest on the unit. The unit will be extremely hot when opening, use caution. **Note:** In keep warm food will continue to cook so it is important to cancel or unplug the unit to avoid food burning.

CLEANING

Clean detachable lid, inner pot, and gasket after each use. Allow adequate time after cooking process to ensure unit is cool. To clean the detachable lid and gasket use water and non-abrasive liquids and sponge, dry with a soft cloth. Be sure that they are placed into the correct position for next use. To clean the inner pot, use non-abrasive liquids and sponges as to not damage the coating, dry with a cloth. **Note:** The unit is not dishwasher safe.

How to Clean the Lid:

1. Lift the lid up directly.
2. Pull the aluminum plate off the lid to clean.
3. Push the aluminum plate back onto the lid before next use.



STORAGE

1. Unplug the cord
2. Make sure all parts are clean and dry.

Recipes:

White Rice

White Long Rice

Cup water or stock

1 teaspoon salt

1 teaspoon extra-virgin olive oil

Place rice in a strainer and rinse rice until water runs clear.

Fill the cup provided with white rice to the 3/4 line.

Fill the inner pot to the line marked 1 on the rice side.

Press rice. Once finished cooking the unit will go into the warm setting.

When cooking time is complete, fluff rice and serve warm.

Brown Rice

Brown rice

Cup of water or stock

1 teaspoon salt

1 teaspoon extra-virgin olive oil

Place rice in a strainer and rinse rice until water runs clear.

Fill the cup provided with brown rice to the 3/4 line.

Fill the inner pot to the line marked 1 on the rice.

Press rice. Once finished cooking the unit will go into the warm setting.

When cooking time is complete, fluff rice and serve warm.

Oatmeal

Old Fashioned Rolled Oats

Water

1/4 teaspoon salt

Fill the cup provided with quinoa to the 1/2 line.

Fill the inner pot to the line marked 0.5 Oats.

Press grain. Once finished cooking the unit will go into the warm setting.

Quinoa

Quinoa

Water

1/4 teaspoon salt (if desired)

Fill the cup provided with quinoa to the 3/4 line.

Fill the inner pot to the line marked 1 Quinoa.

Press grain. Once finished cooking the unit will go into the warm setting.

Responsible party

Company: HSNi, LLC

Address: 1 HSN Dr Building F 2nd Floor St. Petersburg, FL 33729

Tel: 888-311-1476

Website: www.hsn.com