

KITCHEN HQ

MICROWAVE SANDWICH MAKER INSTRUCTION MANUAL



Read this booklet thoroughly before using and save it for future reference.



WARNINGS

Surface can get hot when using so please use oven gloves and use caution.

When using this Microwave Sandwich Maker, handle all hot surfaces with oven gloves or similar.

The Microwave Sandwich Maker is suitable for a microwave oven operating in microwave mode only.

Do not use with a microwave that is greater than 1200W.

WARNING: Handling hot surfaces with wet oven gloves can produce steam causing serious burns to skin.

Do not use for longer than 25 minutes continuously. If the item is used twice in a row, 25 minutes each time, please allow to cool before using again.

Do not cook with Microwave Sandwich Maker when it is empty in Microwave.

WARNING: DO NOT preheat the Microwave Sandwich Maker.

WARNING: DO NOT exceed 15 Minutes for each period of cooking. If additional 'cook time' is needed, allow it to cool down first.

Designed for home use only.

Should sparking or any other unusual malfunction occur during cooking, cut the power to the microwave immediately and contact customer service.

CAUTION:

This set is designed to be used with a microwave that incorporates a turntable. It is possible to use with a microwave that does not have a turntable. For better results flip the sandwich maker.

Please note when using both cooking vessels at once the cooking time should be extended to allow proper cooking.

All parts are dishwasher safe, however, to prolong the life of the non-stick please hand wash.


Allow to cool before washing and completely dry before storing.

Do not use knives or utensils with sharp edges as it may damage the nonstick.


KNOW YOUR ITEM

Check all components included and ensure there is no damage. Remove all packaging materials and any possible protective films used for protection during transportation. Never remove the rating label and any warnings.

What is included:



CONTENTS













BEFORE FIRST USE

- 1.Remove all packaging and wash all pieces before first use.
- 2.Lightly brush the internal part of the sandwich maker with cooking oil.
- 3.Add food and place lid on top and place in center of microwave.
- 4.Cook for desired time until food is done to your likeness. See cooking chart for reference and recipes.
- 5.If your microwave does not have a turntable you may need to turn half-way through cooking.
- 6.Use oven gloves to remove from microwave oven.
- 7.Allow to cool and remove food and enjoy.

CARE AND MAINTENANCE

- 1.Allow your microwave sandwich maker to cool before washing.
- 2.Recommended to clean after every use.
- 3.Allow to dry completely before storing.
- 4.Do not use any abrasive or sharp cleaning products as they may damage the nonstick surface.

ASSEMBLY INSTRUCTIONS



Disassembly:

Open the product, remove the plastic frame, and then gently press the silicone cover to remove the plate.


Installation:

Tilt the plate slightly and press into the silicone cover, then press the plastic frame into the holes of silicone cover.

USING THE ITEM


Step 1:

Put a piece of sliced toast onto the bottom plate, then put other food onto the toast such as cheese, vegetables, eggs, etc.




Step 2:

Place the upper plate onto the bottom plate.




Step 3:

Clip and lock in place.



Step 4:

Place into the microwave oven, cook for 3-4 minutes, and remove!



RECIPES

Crispy Ham and Cheese

Ingredients:

2 slices white bread

1oz cheddar cheese,sliced

2.5oz ham,thinly sliced

Instructions:

Place a slice of bread in the bottom part of your Kitchen HQ Microwave Sandwich Maker, followed by the ham and cheese.Add the other slice of bread, followed by the top of the Sandwich Maker and press to enclose and shape.Microwave for 2 – 2 ½ minutes or until golden brown and crispy.Enjoy!

Reuben Sandwich

Ingredients:

2 slices rye bread

2 tbsp Thousand Island dressing

2 tbsp sauerkraut

1oz Swiss cheese, sliced

2.5oz corned beef, thinly sliced

Instructions:

Place a slice of rye bread in the bottom part of your Kitchen HQ Microwave Sandwich Maker, followed by the dressing,sauerkraut,cheese,and beef.Add the other slice of bread, followed by the top of the Sandwich Maker and press to enclose and shape.Microwave for 2 – 2 ½ minutes or until golden brown and crispy.Enjoy!

Crispy Ham and Cheese

Ingredients:

2 slices white bread

1oz mozzarella, sliced

3 tbsp sundried tomato pesto

Fresh basil, picked

Instructions:

Place a slice of bread in the bottom part of your Kitchen HQ Microwave Sandwich Maker, followed by the pesto, cheese, and basil. Add the other slice of bread, followed by the top of the Sandwich Maker and press to enclose and shape. Microwave for 2 – 2 ½ minutes or until golden brown and crispy. Enjoy!

Pizza Pocket Sandwich

Ingredients:

2 slices white bread

1oz mozzarella, sliced

3 tbsp tomato sauce

2oz pepperoni

1 tsp oregano

Fresh basil, picked

Instructions:

Place a slice of bread in the bottom part of your Kitchen HQ Microwave Sandwich Maker, followed by the cheese, tomato sauce, pepperoni, and oregano. Add the other slice of bread, followed by the top of the Sandwich Maker and press to enclose and shape. Microwave for 2 – 2 ½ minutes or until golden brown and crispy. Enjoy!

Turkey and Bacon Sandwich

Ingredients:

2 slices whole wheat bread

1oz gouda cheese, sliced

2.5oz turkey, thinly sliced

1oz bacon, cooked

¼ avocado, sliced

Instructions:

Place a slice of whole wheat bread in the bottom part of your Kitchen HQ Microwave Sandwich Maker, followed by the cheese, turkey, bacon, and avocado. Add the other slice of bread, followed by the top of the Sandwich Maker and press to enclose and shape.

Microwave for 2 – 2 ½ minutes or until golden brown and crispy. Enjoy!

3-Cheese Grilled Cheese!

Ingredients:

2 slices white bread

1oz cheddar cheese, sliced

1oz mozzarella, sliced

1oz white cheddar, sliced

Instructions:

Place a slice of bread in the bottom part of your Kitchen HQ Microwave Sandwich Maker, followed by the cheddar, mozzarella, and white cheddar cheese. Add the other slice of bread, followed by the top of the Sandwich Maker and press to enclose and shape.

Microwave for 2 – 2 ½ minutes or until golden brown and crispy. Enjoy!

Chocolate Hazelnut Stuffed French Toast

Ingredients:

2 slices French Toast
2 tbsp Chocolate Hazelnut Spread
Powdered sugar, for dusting

Instructions:

Place a slice of French Toast in the bottom part of your Kitchen HQ Microwave Sandwich Maker, followed by the chocolate hazelnut spread. Add the other slice of French Toast, followed by the top of the Sandwich Maker and press to enclose and shape. Microwave for 2 – 2 ½ minutes or until golden brown and crispy. Enjoy!

Bacon, Egg, and Cheese Sandwich

Ingredients:

2 slices white bread
1 egg, scrambled
2oz bacon, cooked
1oz, cheddar cheese, sliced

Instructions:

Place a slice of bread in the bottom part of your Kitchen HQ Microwave Sandwich Maker, followed by the cheese, egg, and bacon. Add the other slice of bread, followed by the top of the Sandwich Maker and press to enclose and shape. Microwave for 2 – 2 ½ minutes or until golden brown and crispy. Enjoy!

HSN Inc.
1200 Wilson Drive
West Chester PA, 19380
Website: www.hsn.com
Made in China.