Trexonic

Channel Scan Guide



Channel Scan Operation

- 1. Press **MENU** to open settings.
- 2. Press direction ▲ ▼ keys to select CHANNEL.
- 3. Press **ENTER** to go to the CHANNEL menu.





 Press ► to select Yes to initiate AUTO SCAN.



5. Choose **AUTO SCAN** with ▼ and press **ENTER** to confirm your choice.



7. System will now run **AUTO SCAN**. Please wait for scan to complete.

NOTE: Charge time 4 - 5 Hours for full charge.

st Please check for signals that are available in your location using **nocable.org**

Play Time: 2 - 3 Hours based on brightness.