
# 尺寸: 284(D)\*90(H) mm



# Applicable Devices

- 1. Devices with built-in quick charge/normal charge wireless receiver.
- 2. Devices with outer-face wireless charging receiver.
- 3. Devices with wireless charging receiver in its protection case .


### Note: All devices must be Qi standard.

## Instructions

#### 1. Wireless chare

Connect the wireless charger to AC power through the power adapter, the wireless charger turns on, the indicator light flashes red and blue once each, then turns red and long and enters standby mode.

Put the phone on the wireless charging area and the phone starts charging. The blue light of the indicator light is on for a long time, and when the phone is fully charged, the blue light goes off.



## 2.Desk lamp:

[1]Short press to turn on the desk lamp, three levels: white light, warm yellow light, warm white light, off, cycle in sequence.

[2]Brightness: rotate clockwise, Darkness: rotate counterclockwise.
[3]Long press to turn off, short press to turn on the default last brightness.
(without cutting off the power)

#### 3. Clock:

[1]. Short press the power button to adjust the light brightness. The default setting is the darkest. The first short press is for medium brightness, the second short press is for the brightest, and the third short press is for the darkest. Cycle in sequence. Long press the power button to turn the display on or off.

[2].Long press the M button to switch between 12-hour and 24-hour formats. 12-hour format: The AM light will be on from 12:00 to 11:59 in the morning. The PM light will be on from 12:00 to 23:59 in the afternoon.

[3] Clock setting: Short press the M key to enter the clock setting interface, and then adjust the "hour" and "minute" in sequence. After entering the interface, the two numbers on the left of the time zone to be set will flash. Press the plus or minus buttons to adjust the current clock number. Short press the M key again, and the two numbers on the right of the clock will start flashing. Press the plus or minus buttons to adjust the current minute number.

[4]Alarm setting: After adjusting the clock, press the M key again to set the alarm time in minutes (set it the same as the clock, and the alarm indicator will flash); then press the M key to exit. Press and hold the M key for 3 seconds or no operation for 10 seconds to exit the setting interface by default.

[5]Alarm setting on and off: Press and hold the plus button for 2 seconds to turn on the alarm, and the alarm indicator light in the middle will be on; press and hold the plus button for 2 seconds to turn it off, and the light will go out (indicating that the

[6]The alarm will ring twice every 25 seconds with an interval of 10 seconds. Pressing the M key will enter snooze mode with a 5-minute snooze. The other two keys can cancel the alarm.

# Specifications

Model No.:3IN1CLK Output power:15W
Input voltage: 9V-12V/3A Charging efficiency: 70%-80%

# Attention

- Please keep the charger away from water or other liquid.
- 2. If you need to clean the charger, please make sure it is power off.
- Using Environment temperature remain 1-45°C degree.